

WHY SAFECOOK™

Imagine: You turn on the stove and put a pan on it.

The telephone rings or someone knocks on the door. You start a conversation that lasts longer than intended, and you forget something is on the stove.

Or even worse, you leave the house without turning off the stove.

When you come back, you discover the damage done in your absence.

Now you can rest assured that if you forget to turn off the stove, Safecook™ will do it for you!

Safecook™ is perfect for you if:

- ✓ You are starting to lose your independence.
- ✓ You are responsible for someone and are afraid of leaving them alone.
- ✓ You often have children playing in the kitchen that could accidentally turn on the stove.
- ✓ You know someone who was the victim of a fire and you are afraid that it will happen to you someday.

IT COULD HAPPEN TO YOU

Since 1998, the number of building fires has increased by 3% annually for an average of 10,800 fires between 2003 and 2005.

The second leading cause of fires (1 in 5) is carelessness while using a cooking appliance. In 2002, five people died.

These statistics do not take into account damages caused by forgotten electric stoves:

- ✓ melted pans
- ✓ destroyed heating elements
- ✓ damaged floors
- ✓ ruined cabinets
- ✓ nervous shock suffered by the victim



EASY TO USE!

Anyone can learn how to use Safecook™!

All you do is turn the timer knob clockwise to the estimated time needed for your cooking use. then, use the stove as usual.

At the end of the selected time delay, the stove's electrical supply will be shut-off.

Perfect for individuals:

- ✓ who are starting to lose their independence;
- ✓ with a mental impairment;
- ✓ with Alzheimer's disease;
- ✓ simply looking for added safety in their kitchens.

Discover **Safecook™!**



BRIEF DESCRIPTION

Regular Safecook™: Once the timer is set, the stove works until the end of the pre-set period and automatically turns off when the timer is finished.

OR

Intelligent Safecook™: lorsque la minuterie est activée, la cuisinière vérifie s'il y a un élément en fonction, si oui rien ne fonctionnera, sinon, la cuisinière démarrera, vous pourrez ainsi ouvrir un élément. La cuisinière fonctionnera pendant toute la durée prédéfinie et s'arrêtera automatiquement lorsque le temps sera écoulé.

With...

Normal Timer: Activates with the simple twist of a button. The stove will work until the timer reaches zero.

Timer Lock: Once the timer is set and the activation key is set to "ON," the stove will work until the timer reaches zero. If the key is set to "OFF," the stove will be locked.

Timer Bypass: Once the key is set to "ON," your stove will work just as it did before Safecook™ was installed. If the key is set to "OFF," the stove will work until the end of the pre-set period and automatically turn off when the timer is finished.

Automatic Timer: Simply turn on your stove and the timer will automatically start. The stove will work until the timer reaches zero.

For more information:

Phone : (418) 386-5800

Fax : (418) 386-5811

E-Mail : info@safecook.ca

WebSite : www.safecook.ca



Made in Canada by Protection E.M. inc.

This product has a 1-year manufacturer's guarantee on parts and labour.

Safecook™



3103605

The only product in its class certified for Canada and the United States.

Safecook



Automatic Shut-Off System for Electric Stoves

- ✓ Easy to install
- ✓ Easy to use
- ✓ Safe and reliable